



Linac Acceptance

J. Scott Berg Advanced Accelerator Group Meeting 10 February 2005



Linac Analysis Procedure




- Analyze linac based on smoothed approximation
- Accelerate total energy 290 MeV to 1.5 GeV
- Choose phase and gradient as a function of energy
 - Transit time factor depends on energy
 - Length of cryomodule depends on energy
- For this example, assume constant gradient, 8.5 MV/m
 - Lowest real-estate gradient in real linac
 - Include transit time factor in addition to this
- Phase profile (0 is crest)


$$\phi(E) = \phi_0 \frac{(E - E_{\min})}{E_{\max} - E_{\min}}$$

• Look at different values of ϕ_0
































Emittance vs. Initial Phase







Concluding Remarks



- Starting further off-crest gives significant improvement in acceptance
 - Cost will be longer linac!
 - Decays may negate gain (need to optimize)
 - Gain may be leveling off (?)
- Need to get bunch from 200 MeV/c
- Consider non-linear phase profile: add quadratic
- Put in increasing gradient as energy goes up